Ground Smart RUBBER GENERATOR PAD

INSTALLATION INSTRUCTIONS



1. BEFORE YOU BEGIN

- Verify compatibility. The GroundSmart Rubber Generator Pad is designed for 10–28 kW air-cooled generators (e.g., Generac, Kohler, Champion) with a maximum footprint of 54" x 32" x 2" per pad. Two pads stacked provide a 4" total height.
- Required hardware (not included). 3/8" x 7" zinc-plated lag screws and matching flat washers are needed to secure the generator to the stacked pads.
- Tools you'll need: Tape measure, carpenter's level, driver with 9/16" socket or driver for lag screws, safety glasses & gloves.
- Observe clearances as per the manufacturer's installation manual and local codes.

2. PREPARE THE SITE

- Select a level, well-drained location that meets all stand-off and exhaust-direction requirements.
- Lay down and compact crushed stone at least the size of the GroundSmart Rubber Generator Pad footprint.
- Verify the surface is flat and level in both directions.

3. STACK THE PADS

- Place the first GroundSmart Rubber Generator Pad on the prepared base; check for level.
- Align the second GroundSmart Rubber Generator Pad directly on top of the first, matching all edges so the combined stack is 4" high.
- Confirm the two pads sit flush with no debris in between.

IMC Outdoor Living, a division of Liberty Tire Recycling 2280 Schuetz Road, Suite 201, St. Louis, MO 63146 groundsmart.com • imccs@imcoutdoorliving.com

4. MOUNT & ANCHOR THE GENERATOR

- Center the generator base on the stacked GroundSmart Rubber Generator Pads.
- Insert a 3/8" x 7" lag screw fitted with a flat washer through each mounting hole and tighten until the washer seats firmly against the generator base.
- Tighten all lag screws evenly.
- Re-check that the generator is level; shim the crushed-stone sub-base if necessary.

5. FINAL CHECKS

- Confirm the GroundSmart Rubber Generator Pads are flush, stacked edges aligned, and generator does not rock or shift under light force.
- Verify required clearances around the generator are according to manufacturer's specifications and local codes.

WARRANTY & SUPPORT

GroundSmart[™] Rubber Generator Pad is backed by a Limited 10-Year Warranty covering defects in materials, workmanship, and UV functional degradation under normal residential use; warranty is limited to repair or replacement of the pad–labor, removal, re-installation, and shipping costs are not covered. Retain proof of purchase and obtain an RMA before returning any product.

QUESTIONS?

Email: imccs@imcoutdoorliving.com Phone: 866-936-8524





We're committed to improving sustainability through innovative ways to reclaim, recycle and reuse end-of-life tires. Our goal is to make the world a better place, it's at the core of what we do.